



FLEXIBLE STAND-UP BOOT

Flexible PVC boot to mount under ratchet blocks. Keeps your block from hitting the deck without snagging lines and it won't hurt your toes.





WWW.OPTIPARTS.COM



Installation step by step:

- 1. Make sure you have the necessary tools:
 - Hairdryer or warm water
 - 2x zip ties
- **2.** Soften the "boot" with a hairdryer or soak the "boot" in warm water.
- **3.** Take the two zip ties and loop them through each side of the "boot".
- 4. Pull the zip ties tight until the "boot" compresses.
- 5. Attach your block to the eyestrap.
- 6. Cut the zip ties.
- **7.** The shape of the "boot" returns to normal when the "boot" cools down.



WARNING:

- Do not burn the "boot".



Photo by: Matias Cappizzano