

**Item no.:**

**EX 3010**

# **REGATTA TIMER**

**Instruction manual:**

- 1. Press MIN to set desire countdown time.**
  - 2. Press START/STOP to begin countdown.**
  - 3. To pause or resume countdown, press START/STOP again.**
  - 4. To synchronize during countdown on the full minute press SYNC.**
  - 5. The alarm beeps every minute, every 10 sec the last minute, every second the last 10 seconds.**
  - 6. To switch on/off sound press the sound button on the back of the timer**
  - 7. On the starting signal the display will return to last entered time.**
  - 8. To clear the memory, press both MIN and SYNC.**
- The timer will auto shut-off after 60 min idle time.**
  - Change battery when display becomes dim.**
  - Grease seal when replacing battery**
  - This unit meets the waterproof requirements for IP67 standard.**

**Warrantee card:**

**This product is warranted for a period of 2 years after purchase. If any defect due to faulty materials or workmanship occurs within this period Optiparts will repair or replace the product at its expense.**

**A defective product should be returned to the dealer or shop where purchased accompanied by a receipt and this warranty card.**

**The warrantee is not valid if a defect is caused by incorrect use or poor maintenance.**

**WINDESIGN IS A TRADEMARK OF OPTIPARTS MARINE EQUIPMENT  
WWW.OPTIPARTS.COM**